

(B) AMD 486 CPU Type Selection

	Am486DX/DX2 V8T/NV8T	Am486DX4 NV8T	Am486DX2 SV8B	Am486DX4 SV8B	Am5x86-P75-133/160
JP21	OPEN	OPEN	SHORT	OPEN	SHORT
JP22	OPEN	OPEN	2-3	2-3	2-3
JP27	OPEN	OPEN	2-3	2-3	2-3
JP28	OPEN	OPEN	OPEN	OPEN	OPEN
JP29	OPEN	OPEN	1-2	1-2	1-2
JP30	2-3	2-3	2-3	2-3	2-3
JP33	OPEN	OPEN	4-5	4-5	4-5
JP36	4-5	4-5	1-2	1-2	1-2
JP41	OPEN	OPEN	SHORT	SHORT	SHORT
JP43	2-3	1-2	OPEN	OPEN	OPEN
JP44	1-2, 3-4	1-2, 3-4	1-2, 3-4	1-2, 3-4	1-2, 3-4
JP48	OPEN	OPEN	1-2, 3-4	1-2, 3-4	1-2, 3-4

Note : JP43-Am486DX2/DX4 SV8B, Am5x86-P75 CPU Internal CACHE Write-Back or Write-Through Selection BOTH JP26/JP43 need to be set to change Cache mode

JP43+26	CACHE Mode
1-2	Write-Back
2-3	Write-Through

(C) Cyrix 486 CPU Type Selection

	CX486SX (M6)	CX486DX/DX2 (M7)	CX486DX4	CX5x86
JP22	1-2	1-2	1-2	2-3
JP27	OPEN	OPEN	2-3	2-3
JP28	2-3	2-3	2-3	OPEN
JP29	OPEN	2-3	2-3	1-2
JP30	OPEN	2-3	2-3	2-3
JP33	2-3	2-3	2-3	4-5
JP36	4-5	4-5	4-5	4-5
JP41	SHORT	SHORT	SHORT	SHORT
JP44	2-3	1-2, 3-4	1-2, 3-4	1-2, 3-4
JP48	2-3	2-3	2-3	1-2, 3-4