WD37C65B
FLOPPY
CONTROLLER

logic diagram

Pin	Name	Dir	Description
2	/REDWC	←	Density Select
4	n/c		Reserved
6	n/c		Reserved
8	/INDEX	←	Index
10	/MOTEA	→	Motor Enable A
12	/DRVSB	→	Drive Sel B
14	/DRVSA	→	Drive Sel A
16	/MOTEB	→	Motor Enable B
18	/DIR	→	Direction
20	/STEP	→	Step
22	/WDATE	→	Write Data
24	/WGATE	→	Floppy Write Enable
26	/TRK00	←	Track 0
28	/WPT	←	Write Protect
30	/RDATA	←	Read Data
32	/SIDE1	→	Head Select
34	/DSKCHG	←	Disk Change/Ready