## GT5600 - Jumper Settings

CPU speed/voltage support may be dependent upon motherboard/BIOS revision

Bus Speed	JP1	JP2
66MHz Bus	Ì	Ì
100MHz Bus	Ņ,	<b>М</b> ,

CPU	JP4				
Multiplier	1-2	3-4	5-6	7-8	
3.0x		Ì		<u>  </u>	
3.5x			<u>  </u>	<mark>]]</mark>	
4.0x		<u>  </u>		Ì	
4.5x	)	<u>  </u>	<u>  </u>	)	
5.0x	)	<u>  </u>	M	<mark>]]</mark>	
5.5x		<u>  </u>	<u>  </u>	<mark>]]</mark>	
6.0x		<u>  </u>	<u>  </u>	<u>  </u>	

\* Product specifications subject to change without notice.