HEWLETT-PACKARD COMPANY
HP VECTRA 486U PC SERIES

Processor	80486SX/80487SX/80486DX/80486DX2
Processor Speed	25/33/50(internal)/66(internal)MHz
Chip Set	HP
Max. Onboard DRAM	64MB
Cache	None
BIOS	HP
Dimensions	276mm x 325mm
I/O Options	Bus mouse port, floppy interface, IDE interface, serial ports (2), parallel port, VGA port
NPU Options	None

HEWLETT-PACKARD COMPANY
HP VECTRA 486U PC SERIES

CONNECTIONS			
Purpose	Location	Purpose	Location
VGA port	CN1	Parallel port	CN4
Serial port 2	CN2	Bus mouse port	CN5
Serial port 1	CN3		

USER CONFIGURABLE SETTINGS		
Function	Switch	Position
í Factory configured - do not alter	SW1/2	Off
í Factory configured - do not alter	SW1/3	Off
í VGA port enabled	SW1/4	Off
VGA port disabled	SW1/4	On
í CMOS memory normal operation	SW1/1	Off
CMOS memory clear	SW1/1	On
í Password check enabled	SW1/2	Off
Password check disabled (password clear)	SW1/2	On
í Security mode disabled (CMOS setup may be changed)	SW1/3	Off
Security mode enabled (CMOS setup may not be changed)	SW1/3	On
í BIOS write protect enabled	SW4	position 2
BIOS write protect disabled (BIOS may be upgraded from disk)	SW4	position 1

DRAM CONFIGURATION				
Size	Bank 0	Bank 1	Bank 2	Bank 3
4MB	(2) 512K x 36	NONE	NONE	NONE
8MB	(2) 512K x 36	(2) 512K x 36	NONE	NONE
12MB	(2) 512K x 36	(2) 512K x 36	(2) 512K x 36	NONE
16MB	(2) 512K x 36	(2) 512K x 36	(2) 512K x 36	(2) 512K x 36
16MB	(2) 2M x 36	NONE	NONE	NONE
20MB	(2) 2M x 36	(2) 512K x 36	NONE	NONE
24MB	(2) 2M x 36	(2) 512K x 36	(2) 512K x 36	NONE
28MB	(2) 2M x 36	(2) 512K x 36	(2) 512K x 36	(2) 512K x 36
32MB	(2) 2M x 36	(2) 2M x 36	NONE	NONE
36MB	(2) 2M x 36	(2) 2M x 36	(2) 512K x 36	NONE
40MB	(2) 2M x 36	(2) 2M x 36	(2) 512K x 36	(2) 512K x 36
48MB	(2) 2M x 36	(2) 2M x 36	(2) 2M x 36	NONE
52MB	(2) 2M x 36	(2) 2M x 36	(2) 2M x 36	(2) 512K x 36
64MB	(2) 2M x 36	(2) 2M x 36	(2) 2M x 36	(2) 2M x 36

HEWLETT-PACKARD COMPANY
HP VECTRA 486U PC SERIES

CPU TYPE CONFIGURATION			
Type	SW3/1	SW3/2	SW3/3
80487SX-25MHz	Off	Off	Off
ODP486SX-50MHz	Off	Off	Off
ODP486SX-66MHz	Off	Off	On
80486DX-33MHz	On	On	On
80486DX2-50MHz	On	On	Off
80486DX2-66MHz	On	On	On
Note: Install the 80487SX or ODP486SX processors in the Upgrade CPU socket.			

VRAM CONFIGURATION	
Size	Bank 0
512KB	NONE
1024KB	(4) 44256

VRAM SWITCH CONFIGURATION	
Size	SW1/1
512KB	Off
1024KB	On