Additional jumper information related to chipset and cpu socket. Helps to configure board correctly for CPUs which are not documented in motherboard's manual.

JP44: Multiplier. 1-2=4x, 2-3=3x

JP18: DACK1. 1-2=Pull-down, 2-3=Pull-up

JP19: DACKO. 1-2=Pull-down, 2-3=Pull-up

J14: pull-down CPU B13 "WB/WT"

J11: pull-up CPU B13 "WB/WT"

J12-1: CPU B12 "Cache"

JP29-2: CPU A12 "HITM"

JP28-1 = pull-up

JP28-2 = CPU A10 "INV"

JP28-3 = CHIPSET 104 "W/R"

JP8-2: CHIPSET 118 "PCD"